

Call Transfer (Blind)

While engaged in a call;

- Press Transfer (or flash-hook on phone if using ATA). The initial call is now being held.
- 2. Enter the complete phone number or extension number of the destination party. Press # to signal the end of the phone number or extension you are dialing.
- 3. Press Transfer (or flash-hook) again. to connect parties.

Call Transfer (Supervised)

While engaged in a call:

- Press Transfer (or flash-hook on phone if using ATA). The initial call is held.
- Enter the complete phone number or extension number of the destination party. Press # to signal the end of the phone number or extension you are dialing.
- 3. Consult with the destination party.
- Press Transfer (or flashhook) again to connect parties or press blinking line key to return to original party.

* Direct Voice Mail Transfer

While engaged in a call:

 Press Transfer and * followed by the mailbox (extension) you wish to transfer the call to then press #.

Three-Way Call

While engaged in one call:

- Press Conference (or flashhook using ATA). The initial call is held.
- 2. Enter the complete phone number or extension number of the third party. Press # to signal the end of the phone number or extension number you are dialing.
- When third party is connected press Conference or flash-hook again. All parties are connected.
- * Note: If either of the two other parties hangs up, your call with the remaining party remains intact. If you hang up, the other two parties will be disconnected.

Feature Access Codes

Call Forwarding

*72 - Call Forwarding Always Activation

- 1. Lift handset and press feature code *72 #.
- Enter the extension number you wish to forward, followed by the # key.
- Enter the complete phone number or extension number the calls will be forwarded to followed by the # key.
- 4. Replace handset. The Call Forwarding service is ON.

*73 - Call Forwarding Always Deactivation

- 1. Lift handset and press feature code *73 #.
- 2. Replace handset. The Call Forwarding service is turned OFF.

*90 - Call Forwarding Busy Activation

- 1. Lift handset and press feature code *90 #.
- 2. Enter the extension number you wish to forward, followed by the # key.
- Enter the complete phone number or extension number that calls will forward to when you are on the phone followed by the # key.
- Replace the handset. The Call Forwarding Busy service is turned ON.

*91 - Call Forwarding Busy Deactivation

- 1. Lift handset and press feature code *91 #.
- Replace handset. The Call Forwarding Busy service is turned OFF.

*52 - Call Forwarding No Answer Activation

- 1. Lift handset and press feature code *52 #.
- 2. Enter the extension number you wish to forward, followed by the # key.
- 3. Enter the complete phone number or extension number that calls will forward to when you do not answer.
- 4. Replace handset. The Call Forwarding No Answer service is turned ON.

*53 - Call Forwarding No Answer Deactivation

- 1. Lift handset and press feature code *53 #.
- 2. Replace handset. The Call Forwarding No Answer service is turned OFF.

Call Park & Pickup

70 - Call Park (no* needed)

- 1. While engaged in a call press Transfer and Dial 70#.
- 2. Take note of the 2 digit number the system reads back to you. Replace the handset, the call is now parked.

71-79 - Call Park Retrieve (no* needed)

 From any phone; lift handset and dial the 2 digit number where the call is parked. You now have the parked call.

*8 - Call Pickup - Group

- 1. Lift handset and press feature code *8 #.
- 2. You will be picking up the longest ringing phone in the pick up group.

** - Call Pickup - Directed

- 1. Lift handset and press feature code ** #.
- Enter the extension where the call is ringing.

*69 - Call Return

1. Lift handset and press feature code *69 #.

*70 - Call Waiting Activate

1. Lift handset and press *70 #.

*71 - Call Waiting Deactivate

1. Lift handset and press *71 #.

*78 - Do Not Disturb Activation

1. Lift handset and press *78 #.

*79 - Do Not Disturb Deactivation

1. Lift handset and press *79 #.

*80 - Hands Free Intercom

1. Dial *80 and the extension you wish to intercom then press #

Paging 1.

- Dial desired paging zone.
- 2. _____ (default zones)
- 3. Make announcement



Feature Access Codes

*80 Intercom prefix

Г	eature Access Codes		
*30	Blacklist a number	*411	Phonebook dial-by-name directory
*31	Remove a number from the blacklist	*45	Queue Toggle
*32	Blacklist the last caller	*0	Speeddial prefix
*72	Call Forward All Activate	*75	Set user speed dial
*73	Call Forward All Deactivate	55	My Voicemail
*740	Call Forward Toggle		
*90	Call Forward Busy Activate		
*91	Call Forward Busy Deactivate		
*52	Call Forward No Answer/Unavailable Activate		
*53	Call Forward No Answer/Unavailable Deactivate		
*70	Call Waiting - Activate		
*71	Call Waiting - Deactivate		
*34	Perform dictation		
*35	Email completed dictation		
*76	DND Toggle		
*78	DND Activate		
*79	DND Deactivate		
*21	Findme Follow Toggle		
*54	User Intercom Allow		
*55	User Intercom Disallow		